

PRE-OPERATION FORKLIFT CHECKS

Lift should only be operated by trained and certified operators

Check the condition of the tilt and lift systems

Check that the load capacity plate is readable and not damaged

Check for damage and cracks in forks and lifting attachments

Check each tire for wear, correct inflation and missing wheel nuts

Check fuel level

Check hydraulic oil level

Check for oil and gas leaks

Check the operation of brakes, hand brake, steering, forklift controls, lights, mirrors, horn and back-up alarm

